MlochM
Friday, June 28, 2002 03:17:35pm
H:\cad\STRUCTURAL\Work_dir\GINGLES\65k's\02123\02123s2.dwg
Xrefs: H:\cad\ARCHITECTURAL\GINGLES\02123 Conyers_GA(#469)\02123COR.dwg H:\CAD\ARCHITECTURAL\GINGLES\99370_80K Prototype\PHARMACY\65kwait.dwg H:\cad\ARCHITECTURAL\GINGLES\99370_80K Prototype\PHARMACY\PHARM-2.dwg H:\cad\ARCHITECTURAL\GINGLES\02123 Conyers_GA(#469)\TITLE469.dwg

NOTES:

1. PROVIDE LEVEL SURFACE FOR STUD WALL. SLOPE CONCRETE FROM INSIDE STUD WALL TO DRAIN.
2. (D.) INDICATES FLOOR DRAIN. SEE PLUMBING PLAN FOR SIZE, INVERT, AND LOCATION.
3. PROVIDE BLOCKOUT OR SET TRENCH DRAINS BEFORE SLAB PLACEMENT. COORDINATE LOCATION AND SIZE ON SHEET P-1 OF PLUMBING PLAN.
4. COORDINATE LOCATION OF REFRIGERATION PIPING PITS WITH DRAWING M-4.
5. FLOOR AND SIDEWALK SLAB SHALL BE 4" THICK CONCRETE ON 4" COMPACTED GRAVEL FILL OVER 6 MIL POLYETHYLENE VAPOR BARRIER. REINFORCE WITH 6x6-W2.9xW2.9 @ CENTER OF SLAB. SEE PLAN FOR FINISH FLOOR ELEV. MAINTAIN A MINIMUM 4" THICKNESS OF SLAB IN RECESSED AND SLOPED AREAS.
6. LOCATE CONTROL / CONSTRUCTION JOINTS AT COLUMN CENTERLINES. PROVIDE ADDITIONAL CONTROL JOINTS IF REQUIRED TO MEET SECTION 6A OF THE GENERAL NOTES.
7. SEE ARCHITECTURAL DRAWINGS FOR CURB CONDITIONS AT FREEZERS AND COOLERS.
8. REFER TO ARCHITECTURAL DRAWINGS FOR SIDEWALK EXTENTS, PLANTER AND PAVER LOCATIONS AND DETAILS.
9. PROVIDE A 6 MIL (MINIMUM) POLYETHYLENE VAPOR BARRIER WITH JOINTS LAPPED 6" AND TAPED UNDER ALL INTERIOR SLABS.

FINISHED FLOOR ELEV=867'-0"

(CONCRETE ELEV. BELOW DRAIN)
SLOPE CONCRETE TO FLOOR DRAIN WITH APPROXIMATE DIMENSIONS SHOWN (2'-0" RADIUS UNLESS NOTED OTHERWISE)

SEE NOTE #6.